

Pairing Instructions for Call-Hear™

Pairing: Using pairing button on chiming unit + Call-Hear sign with button

1. Press the pairing button on the chiming unit until you hear a beep (you are now in pairing mode).
2. IMMEDIATELY RELEASE YOUR FINGER FROM THE PAIRING BUTTON AS SOON AS YOU HEAR THE BEEP - the red led will light up.
3. Press and release the button alternately to choose which colour led light you want to pair with the sign (each colour will light up in turn).
4. When the led colour you want is lit, take your finger off the pairing button and immediately press it again, while at the same time pressing the yellow button on the Call-Hear sign.
5. Keep pressing both buttons till you hear a beep. The led colour you chose will then light up together with the strobe light and a chiming noise will be heard. (RELEASES THE BUTTONS AS SOON AS YOU HEAR THE BEEP).

Un-pairing: Using pairing button on chiming unit

1. Hold the pairing button down until you hear a beep (do not stop pressing).
2. Keep pressing the button until the 3 coloured led lights are lit (you are now in un-pairing mode).
3. Release the button and press the button alternately until the colour you paired in the first place is flashing.
4. Now press the pairing button until you hear a beep and all three lights go off. You are now un-paired.